

Resetting Device Address - PC & LX1

Each GrowNET™ device must be assigned an address number before the system can begin talking to it. All devices come from the factory without an address assigned and must be assigned when first installed.

****The device remembers its address after it has been assigned even if it is disconnected from the system.***

The device address can be reset to factory default by following the steps outlined below.

Tools Required:

- LX1 AgrowLINK USB Tool
- Windows PC with Agrowlink Software Installed (*Available for download at agrowtek.com*)
- RJ-45 Cable
- Agrowtek Device

Process:



- Connect the LX1 and your device to any Windows computer.




- Launch the AgrowLINK software.




- Select “**Read Status**” under Commands to scan the device.



- Select “**Reset**” under Device Address.



- Select “**Read Status**” again to verify the address reset was completed successfully. (0xff = Successful)



```
DEVICE=RX1 ADDRESS=0x1 STATUS=Initialized OK  
OK  
DEVICE=RX1 ADDRESS=0xff STATUS=OK
```

- ❖ The device can now be added to the system as if it were new.

Please contact Agrowtek if you require further support. 847-380-3009